




## GSMS-SW22T AC/DC QUICKSTART GUIDE

To use the unit a SIM-card is required.

1. Make sure the SIM-card has balance and that the PIN-lock is disabled.
2. Install the SIM-card first then connect the unit and power on.



3. Wait a couple of minutes for the red “STA” led to turn off.  
If it starts to blink something is wrong, refer to complete manual.
4. Send an SMS to the unit containing “SW0000CHECK”, wait for a reply.
5. Grab the app from Appstore or Google play and add the unit.



GSMS Remote Control  
Utilities

GET

6. In the app go “Settings” > “Select profile” > “Create” and fill in the details.

|                       |   |
|-----------------------|---|
| Profile name:         | What you want to call the profile       |
| Password for unit:    | If unit is new use “0000” = four zero's |
| Phone number to unit: | Phone number to installed SIM-card      |
| Select unit:          | Select “GSMS-SW22T/TB/TBD”              |

7. Download the complete manual. Save on your computer or a USB-stick!

Complete manual found here:  
[www.gsm-start.com/sw22t\\_en](http://www.gsm-start.com/sw22t_en)

PIERR   
AUTOMATIK AB